

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://unitronic.nt-rt.ru> || uci@nt-rt.ru

Tower Battery Cabinets For UPS



UPS Battery Cabinets can put batteries inside safely and look good, and save space. Distribution cabinets configured for UPS are generally used for UPS output distribution, so UPS distribution boxes are generally UPS output distribution boxes. It can control distribution units, rack-mounted distribution units and central power distribution, which is easy to manage. Tower Battery Cabinets are composed of plastic front panels and steel casings, which can be perfectly matched with single-phase 1-20kVA UPS. Anderson Terminals are used to connect UPS and battery cabinets, which is easy to connect. Tower battery packs are equipped with battery circuit breakers, which is safer to use. The appearance of the battery cabinet is similar to that of the UPS and looks good.

Model	Voltage of Battery String (Vdc)	Battery Quantity (pcs)	Battery Capacity (Ah)	Size of Battery Breaker (A)	Size of Battery Cable (AWG)	Weight (kg)	Dimension (W*D*H,mm)
UB0224-7AH	24	2	7	63	10	9.5	145*413*224
UB0224-9AH	24	2	9	63	10	10	
UB0424-7AH	24	4	7	63	10	18	
UB0424-9AH	24	4	9	63	10	20	
UB0336-7AH	36	3	7	32	10	12	
UB0336-9AH	36	3	9	32	10	13	
UB0636-7AH	36	6	7	32	10	19	
UB0636-9AH	36	6	9	32	10	20	
UB0448-7AH	48	4	7	63	10	14	

UB0448-9AH	48	4	9	63	10	15	191*417*322
UB0672-7AH	72	6	7	63	10	18	
UB0672-9AH	72	6	9	63	10	20	
UB0672-7AH-16	72	6	7	63	10	22	
UB0672-9AH-16	72	6	9	63	10	23	
UB1272-7AH	72	12	7	63	10	35	
UB1272-9AH	72	12	9	63	10	39	
UB0896-7AH	96	8	7	63	10	26	
UB0896-9AH	96	8	9	63	10	28	
UB1696-7AH	96	16	7	63	10	43	
UB1696-9AH	96	16	9	63	10	48	

UB16192-7AH	192	16	7	63	10	44	251*604*505
UB16192-9AH	192	16	9	63	10	49	
UB32192-7AH	192	32	7	63	10	90	
UB32192-9AH	192	32	9	63	10	96	
UB32192-7AH-20K	192	32	7	125	6	91	
UB32192-9AH-20K	192	32	9	125	6	97	
UB40240-7AH	240	40	7	63	10	109	

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://unitronic.nt-rt.ru> || uci@nt-rt.ru

UB40240-9АН	240	40	9	63	10	117
UB40240-7АН-20К	240	40	7	125	6	110
UB40240-9АН-20К	240	40	9	125	6	118